ProNet Quickstart Adding Production String Packer record

- 1. To add a *Production String Packer* record, first select a *Well* record and a *Day* record from the *Well Operations* and *Day* selectors respectively.
- Next, mouse-over the *ProNet* menu tab and select *Production String Packer* from the drop down menu.
- 3. This will load the **Production String Packer** page, showing the existing record associated with the selected **Well** and **Day** records.

WELL DATA 🖂 RIG DATA 🖂 DrillNet 🖂	GeoNet 🗹	SafeNet 🗹	CostNet 🗹	ProNet ⊻	DAT 🖂	REPORTS	SETUP 🖂
				Daily Com	pletion (Ops	
				Perforatio	m		
				Productio	n Fluid		
				Productio	n String		
				Productio	n String	Fish	
				Productio	on String	Packer	
				Productio	n String	Pressure	
				Productio	n String	Testing	
				Sand Con	trol		
				Stimulatio	m		
				Swabbing	J .		
				Well Prod	luction T	est	
				Wellbore	Properti	es	
				Wellhead			

Figure 1.0 Accessing Production String Packer

4. Create new **Packer**record by clicking the **Add New** button.

Packer Data	File Manager		_			
Add New Delete Selected						
Packer						
Seq. #	Production	n String Instal	l Date Uninstall ()ate Depth	Size	Description
Add Packer)					

Figure 1.1 Add new Production String Packer

5. Enter the **relevant data**.

Packer Data File Man	ager				
	C	onfirm	Cancel		
Packer					
Seq. #	Production String	Install Date		Uninstall Date	
Cancel			c C		C C
Add Packer					

Figure 1.2 : Entering the Packer data

6. To save, click the <u>*Confirm*</u> button.